



Hur man ställer in GARMIN 60CSx  
eller 76CSx för att använda i SDL  
[www.vsk.info](http://www.vsk.info)








System



Display




Interface



Tones



Page Seq.



Map



Routing



Geocache



Marine



Time



Units



Heading



Position Format

**hddd°mm'ss.s"**

Map Datum

N580324 Nddmmss

**WGS 84**

Distance/Speed

**Metric**

Elevation (Vert. Speed)

**Meters (m/sec)**

Depth

**Meters**

Temperature


**Celsius**

Pressure

**Millibars**



# Om din GPS har höjdmätare ex GARMIN 60CSx eller 76CSx





Auto Calibration

On


Barometer Mode

Fixed Elevation

Calibrate Altimeter




## Använd bara Fixed Elevation








System



Display




**Interface**



Tones



Page Seq.



Map



Routing



Geocache



Marine



Time




Units



Heading




**Detta gäller bara serie porten  
används oftast inte  
NMEA använd för att sända live  
data till annan enhet PC eller annat**







**GARMIN läget använd när man vill hämta ut track loggar med serie kabel detta fungerar om GPS saknar USB port men du behöver en seriakabel med POP kontakt Detta e gammalt men fungerar**








Tracks




Routes



High



Setup



Proximity



Calc



Calculator



Stopwatch



Sun







Track Log

On

Off

99%


Setup

Clear

Save


TracBack

Saved Tracks





**Se till att ha loggning på Time**



**Under Data Card Setup**

**finns en ruta**

**Log track to datacard denna kan vara i kryssad  
i så fall har du gamla loggar i flera år i gpx format  
dock inte godkända i SDL men GPSdump  
kan läsa dom helt ok**



Wrap When Full

Record Method

Time

I Distance

Time 03<sub>sec</sub>


Auto

Green











Data Card Setup



# GPSmap 60CSx



The image shows a menu screen on a GPS device. At the top, there is a status bar with a battery icon and a signal strength indicator. Below this, the screen is divided into a grid of 12 menu items, each with a small icon and a text label. The items are arranged in four rows and three columns. At the bottom of the screen, there is a dark blue bar containing the current time and date.

 System	 Display	 Interface
 Tones	 Page Seq.	 Map
 Routing	 Geocache	 Marine
 Time	 Units	 Heading

12:04:15      28-APR-11






Show

Map Name



**Flygsektorer, map  
area, Sep 2009**





Denna kartan kan du få in i en GARMIN GPSmap om du lägger filen [http://arkiv.vsk.info/div\\_filer/gmapsupp.img](http://arkiv.vsk.info/div_filer/gmapsupp.img) i en mapp med namnet garmin på ditt minnes kort till din GPS

